

DAEWOO

ELECTRICALS



Colour Changing LED Bluetooth Speaker

with Qi wireless charging

User Manual



IMPORTANT SAFEGUARDS



When using electrical appliances, basic safety precautions should always be followed. These instructions should be saved for future reference:


- Read and familiarise yourself with all operating instructions before using this Speaker.
- Before plugging your unit into the USB supply, visually check that the unit is intact and has not suffered any transit damage.
- Check that the voltage indicated on the data plate corresponds with that of the local network before connecting the appliance to the power supply.
- Always use this appliance on a solid, level, non-flammable surface.
- Ensure that there is clearance of at least 100mm (4 Inches) minimum around the Speaker for sufficient ventilation.
- Ensure that the ventilation openings are not covered with items, such as newspapers, table-cloths, curtains, etc.
- No naked flame sources, such as lighted candles, should be placed on the Speaker.
- Do not position the Speaker close to sources of heat such as radiators, heaters, other electronic equipment, etc.
- The Speaker shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not immerse the Speaker in water or any other liquids.
- Do not leave the Speaker unattended during use.
- Do not leave the Speaker unattended whilst connected to a USB supply.
- Close supervision is required when using this Speaker near children.
- Never leave this Speaker within reach of children.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be

made by children without supervision.

- Children of less than 3 years should be kept away unless continuously supervised.
- Do not use this Speaker outdoors.
- It is imperative to unplug the power supply after the Speaker has been used, before it is cleaned and whilst being repaired.
- Repairs to electrical appliances should only be performed by qualified personnel. Improper repairs may place the user at serious risk.
- Do not operate this appliance after a malfunction or after being dropped or damaged in any way.
- Do not allow the power cable to hang over sharp edges or come in contact with hot surfaces.
- Do not run the USB power cable under carpets, rugs, etc.
- This product is intended for household use only and should not be used for industrial purposes.
- Do not use any accessories or attachments with this product other than those supplied or recommended by supplier.
- Do not use this product for anything other than its intended use.
- Do not push objects into any openings as damage to the product and/or electric shock may occur.

Description of Parts

1.  – Press to change the light mode.
2.  – Press to Power on/off/Play/Pause/Phone (answer the phone).
3. Wireless Charging Pad.
4. Colour Changing Lights.
5. USB Power Cable.
6. Micro USB plug.





Before the first time you use your Wireless Charging Speaker

Please read these operating instructions thoroughly and keep them in a safe place for future reference. Remove all packing materials and discard responsibly.

Operating Instructions

1. Insert the **Micro USB Plug (6)** of the **USB Power Cable (5)** into the USB socket on the rear of the speaker.
2. Insert the large USB plug on the other end of the **USB Power Cable (5)** into a suitable USB power supply (not included) rated at 5 volts 2 amps minimum.

Using the Bluetooth Mode



1. Touch  (2) on the front to power up the speaker.
2. Enable the Bluetooth mode on your Phone, Tablet or other Bluetooth compatible device and set it to search.
3. Select '**AVS1397**' from the search results found by your device which will now pair and the speaker will chime to confirm pairing.
4. Enable the music player on your Phone, Tablet or other device you are using.
5. Touch  (2) on the front to start and stop (pause) the connected device playing.
6. Alternatively use your devices controls in the usual manner.

Wireless Charging your Phone


1. Ensure the Wireless Charging Speaker is powered as described above.
2. Place your phone on the top of the **Wireless Charging Pad (3)** with the rear of the phone towards the pad.

Handling Telephone Calls



Answering a Call

1. A call coming in will mute (cut) the music you are listening to.
2. Briefly touch  (2) to answer the call.
3. Briefly touch  (2) again to end the call.
4. The callers voice will be heard through the speaker and your voice will be picked up by the built in **Microphone** in the speaker.





Rejecting a Call










1. A call coming in will mute (cut) the music you are listening to.
2. Touch  (2) for two seconds to reject the call.

Re-dialling the last call

1. Touch  (2) and the last call made will be re-dialled.
2. Briefly Touch  (2) again to end the call.

Selecting the Light Mode

- A. Touch  (1) for two seconds for white light mode, touch  (1) to adjust the brightness M-H-OFF.
- B. Touch  (1) for two seconds for white light (blue) colour light mode, once light (blue) mode has been selected, touch  (1) to change to the following modes:

1. Touch  (1) once for solid Blue light
2. Touch  (1) again for 'sound to light' colour changing light mode.
3. Touch  (1) again for slow colour fading mode.
4. Touch  (1) again for 'sound to light' colour changing light mode.
5. Touch  (1) again for flashing colour mode.
6. Touch  (1) again for left to right colour changing light mode.
7. Touch  (1) again for right to left colour changing light mode.
8. Touch  (1) again for slow right to left colour changing light mode.
9. Touch  (1) again to switch off the light.

Care and Use of your Speaker

- Always disconnect the Speaker from the USB charging supply before cleaning.
- Clean outside of the Speaker with a clean damp cloth. Never clean with harsh or abrasive cleaners.
- Do not submerge the Speaker in water or any other liquids.

Technical Specification

Model Number	AVS1397
Power Supply/Charger	DC 5V @2A
Total audio output power	1x 5W
Wireless Charging Power	5W
Unpacked Weight	Approx. 350g
Dimensions (Approx.)	Approx. 140 mm (dia.) x 60mm (h)
Operation temperature	0°C to + 40°C
Bluetooth Frequency Range	2402 - 2480MHz
Bluetooth Transmission power	≤-3.325dBm
This product conforms to Radio Equipment Directive 2014/53/EU	

DAEWOO

ELECTRICALS



GUARANTEE

This product is guaranteed for twenty-four months from the date of original purchase. If any defect should occur due to faulty materials or workmanship, please return it to the store it was purchased from.

You will need to have your receipt of purchase to hand. The guarantee is subject to the following provisions:

- It is only valid within the boundaries of the country of purchase.
- The product must be correctly installed and operated in accordance with the instructions contained in the User Manual.
- The product must be used solely for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- The manufacturer disclaims any liability for incidental or consequential damages.
- The guarantee is in addition to, and does not diminish, your statutory or legal rights.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



Daewoo Electricals is a registered trademark.
Produced and imported under licence by ESG Ltd
Manchester M3 1JS www.esgltd.com