

DAEWOO

ELECTRICALS



Aluminium Bluetooth Cylinder Speaker

User Manual



IMPORTANT SAFEGUARDS


When using electrical appliances, basic safety precautions should always be followed.

These instructions should be saved for future reference:

- Read and familiarise yourself with all operating instructions before using your Cylinder Speaker.
- Before using your Cylinder Speaker, visually check that the unit is intact and has not suffered any transit damage.
- Only charge the speaker from a suitable USB outlet, any other power source may cause permanent damage to the product.
- The speaker must be fully charged via the USB port before use.
- Do not operate this speaker after a malfunction or after being dropped or damaged in any way.
- Never allow children to play with the speaker. Small parts may be a choking hazard.
- Do not allow the USB charging cable to hang over sharp edges or come in contact with hot surfaces.
- This speaker is intended for household use only and should not be used for industrial purposes.
- Do not use this speaker for anything other than its intended use.
- Do not immerse the speaker in water or any other liquids.
- Do not expose the speaker to moisture, rain or humidity, as it is not waterproof.
- Before cleaning, ensure the speaker is not connected to the USB supply.
- Never clean the speaker with solvents or harsh or abrasive cleaners.
- Do not attempt to dismantle the speaker, it does not contain any user serviceable parts.
- Whilst not in use, store the speaker in a cool dry place free from extreme temperatures, humidity or dust.

Description of Parts

1. Speaker Control: Press to Play/Pause/Volume + or -/Next or Previous Track/Answer Phone.
2. USB Port.
3. Micro SD Card Slot.
4. ON/OFF Switch.
5. Micro USB Charging Port.
6. LED Indicator.
7. USB to Micro USB Charging Cable



LED Indicator Modes

- Charging: LED illuminates red.
- Battery Fully Charged: LED extinguished (when powered off).
- Pairing Mode: LED flashes quickly blue.
- Connected: LED illuminates blue.
- Playing Music: LED flashes slowly blue.

Charging Your Cylinder Speaker

Before first using your Cylinder Speaker ensure it is fully charged as follows:

1. Insert the Micro USB plug of the **USB to Micro USB Charging Cable** into the **Micro USB Charging Port** on the Cylinder Speaker.
2. Insert the large USB plug into a suitable USB charger rated to at least 1 Amp. (most chargers are rated 1 Amp or above).
3. Whilst the Speaker is on charge, the **LED** Indicator will glow red, once the internal battery is fully charged the **LED** will go out.
NB Charging time will take approximately 2-3 hours – remove the charging cable once the speaker is fully charged.

Powering Up Your Cylinder Speaker

1. **Power On:** Move the ON/OFF Switch to the right 'ON' position and the **LED Indicator** will flash Blue and a chiming tone will be heard showing the speaker is ready to pair.
2. **Power Off:** Move the ON/OFF Switch to the left 'OFF' position to switch the speaker off.

Pairing Your Cylinder Speaker

1. Power up the speaker as described above and the **LED** Indicator will quickly flash Blue.
2. A chiming tone will be heard to indicate the speaker is powering up and ready to pair.
3. Activate your Bluetooth search mode on your media device and search for '**AVS1345**' in the list shown on your Bluetooth device. Select **AVS1345** from the search results and the speaker will now pair with your device.
4. Once the two are paired successfully you will hear another chiming tone to confirm pairing and the **LED** will now illuminate a steady blue colour.
NB The speaker will reconnect automatically after power up if your device has previously paired with the headphones and the pairing process may not be needed.

Playing Music via Bluetooth after Pairing

1. Press the Speaker Control in to start playing music, press the control in again to pause playing music.
2. Slide and hold the Speaker Control to the right to increase the volume level.*
3. Slide and hold the Speaker Control to the left to decrease the volume level.
4. Briefly slide the Speaker Control to the right to skip to the next music track.
5. Briefly slide the Speaker Control to the left to skip back to the previous music track.
NB whilst playing music, the LED Indicator will flash slowly

Handling Telephone Calls

Answering a Call

1. A call coming in will mute (cut) the music you are listening to.

2. Briefly press the Speaker Control to answer the call.
3. Slide and hold the Speaker Control to the right to increase the volume level.*
4. Slide and hold the Speaker Control to the left to decrease the volume level.
5. Briefly press the **Speaker Control** again to end the call.
6. The callers voice will be heard from the Cylinder Speaker and your voice will be picked up by the built in **Microphone** in the speaker.

Rejecting a Call

1. A call coming in will mute (cut) the music you are listening to.
2. Press and hold the **Speaker Control** for two seconds to reject the call.

Playing Music from a USB memory Stick

1. Insert a USB Memory Stick (not supplied pre-loaded with audio tracks – Mp3, WAV files etc.) into the **USB Port** on side of the Cylinder Speaker.
NB the USB port supports USB 2.0 and up to 32GB capacity max.
2. The tracks on the Memory Stick will begin to play automatically.
3. Slide and hold the Speaker Control to the right to increase the volume level. *
4. Slide and hold the Speaker Control to the left to decrease the volume level.
5. Briefly slide the Speaker Control to the right to skip to the next music track.
6. Briefly slide the Speaker Control to the left to skip back to the previous music track.
NB whilst playing music, the LED Indicator will flash slowly.

Playing Music from a Micro SD Card

1. Insert a Micro SD card (pre-loaded with audio tracks – Mp3, WAV files etc.) into the Micro SD Port on the side of the Cylinder Speaker under the USB port.
NB the Micro SD Card Port supports cards up to 32GB capacity max.
2. The tracks on the card will begin to play automatically.
3. Slide and hold the Speaker Control to the right to increase the volume level. *
4. Slide and hold the Speaker Control to the left to decrease the volume level.
5. Briefly slide the Speaker Control to the right to skip to the next music track.
6. Briefly slide the Speaker Control to the left to skip back to the previous music track.
NB whilst playing music, the LED Indicator will flash slowly.

*Two high pitched beeps will be heard to warn when the maximum volume setting has been reached.

Technical Specification


Model Number	AVS1342, AVS1343, AVS1345 & AVS1347
Power Supply/Charger	DC 5V 1A
Audio output power	5W
Weight	214g
Dimensions (Approx.)	47mm (h) x 92mm (dia.) Approx.
Operation temperature	0°C to + 40°C
Built in Battery type	Li-Polymer, 500 mAh 3.7V
Bluetooth Frequency Range	2402 - 2480MHz
Bluetooth Transmission power	≤-3.325dBm
This product conforms to Radio Equipment Directive 2014/53/EU	



Waste batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

DAEWOO

ELECTRICALS



GUARANTEE

This product is guaranteed for twenty-four months from the date of original purchase. If any defect should occur due to faulty materials or workmanship, please return it to the store it was purchased from.

You will need to have your receipt of purchase to hand. The guarantee is subject to the following provisions:

- It is only valid within the boundaries of the country of purchase.
- The product must be correctly installed and operated in accordance with the instructions contained in the User Manual.
- The product must be used solely for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- The manufacturer disclaims any liability for incidental or consequential damages.
- The guarantee is in addition to, and does not diminish, your statutory or legal rights.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



Daewoo Electricals is a registered trademark.
Produced and imported under licence by ESG Ltd
Manchester M3 1JS www.esgltd.com